

Remote Control



Swing - Distributes cool/warm air to a maximum area by moving flaps automatically.

Sleep - Enables the air conditioner to automatically increase (cooling) or decrease (heating) 1.8 °F / hour for the first two hours, then keep it steady for the next 5 hours, after that will turn off. This function maintains both energy savings and comfort in night operation.

Air Direction - Due to density of cold and warm air is different, in cooling mode indoor unit blows air horizontally, while in

heating mode blows it vertically, to make room temperature more consistent and comfortable during the operation.

Timer - The timer can be set to start ON and stop OFF at any point in a 24 hour operation

Turbo - The air conditioner will maximize the output of cooling or heating operation, make the room cool down or heat up rapidly, and attain the desired temperature in the shortest time

TEMP - Sets the room temperature up or down 1° F at a time.